


# T-Mobile Hot Spot Quick Start Guide

## Components






- 1. Power/Menu Button** – Turn on/off T9. Shows device menu and information

### Button Operation

	Operations	Actions
	Turn On	Press and hold the button for 3 seconds.
	Turn Off	Press and hold the button until "Goodbye" message appears.
	Display Wake-Up	When the display is off (sleep mode), the first quick press of the button wakes up the display.
	Info Display	When the display is on, press the button quickly to go through the device menu and information.

### LED Indicator

	Colors	Charging Status
	Off	Power off.
	Solid	Power off and connected to a charger.
	Blinking	Power on/Operating normally




- 2. Display** – Provides device status information such as battery, service signal strength, the number of users connected with Wi-Fi etc.
- 3. Charger Port** – The USB charger connects here.

# T-Mobile Hot Spot Quick Start Guide

## Connecting to Your T-Mobile Hot Spot

### Wi-Fi Name (SSID) and Password

You can find your Wi-Fi Name and Password any time you need. Just press the power/menu button (🔌) shortly when the display is on.



Press 🔌 quickly

Home screen, Device menu guide  
(Switching every 3 seconds)

Press 🔌 quickly

Data usage display

Press 🔌 quickly

Wi-Fi Name display

Press 🔌 quickly

Password display

Press 🔌 quickly

Web Admin URL Guide display

Press 🔌 quickly

Back to Home screen